



TOP CONNECTION:  
 BOLT STRAP ANCHOR TO  
 CAST-IN INSERT AND WELD  
 TO BEARING ANGLE.  
 CAST-IN INSERT

REBAR AS REQUIRED

MIDDLE CONNECTION:  
 SPLIT-TAIL ANCHOR GROUTED  
 SOLID IN PROVIDED SLOTS  
 IN BOTH PCS OF STONE AND  
 BOLTED BACK TO CMU  
 BACKUP

BOTTOM CONNECTION:  
 COIL CAST-IN INSERT  
 COIL ROD SCREW TO  
 CAST-IN INSERT AND GROUT  
 SOLID IN FIELD DRILLED  
 HOLE IN FOUNDATION  
 BELOW.

8  
 BP

# BASE PANEL CONNECTION

SCALE: 1"=1'-0"

