



CONNECTION:
CAST-IN INSERT. (2) PER PIECE
AT EACH END OF TREAD.
BOLT EACH SIDE OF STAIR TREAD
TO STRUCTURAL BEARING ANGLE.



SECTION A/A

2 STAIR CONNECTION
SCALE: 1"=1'-0"